



# **BUILDING INSULATION RESEARCH**

**PREPARED BY  
ZHWAN ALI KAREEM**

## Table of Contents

Introduction : .....	3
The Importance of Insulation : .....	3
Different Types of Insulation : .....	3
Installation of Insulation : .....	3
Benefits of Insulation: .....	3
Method of Insulation : .....	4
Batt Insulation : .....	4
Blown-In Insulation : .....	4
Spray Foam Insulation : .....	4
Rigid Foam Insulation : .....	4
Capability of materials : .....	5
Fiberglass Insulation : .....	5
Cellulose Insulation : .....	5
Spray Foam Insulation : .....	5
Rigid Foam Insulation : .....	5
Reflective Insulation : .....	5
The U-value of a building : .....	6
Door, window and curtain wall insulation of building : .....	7
Facade Insulation of a building : .....	9
Sound insulation of building : .....	10
Mass : .....	10
Absorption : .....	10
Damping : .....	10
Isolation : .....	10
Sealing : .....	10
Design : .....	10
Table of comparison : .....	11
Examples of how to calculate U value : .....	12
Conclusion : .....	14

## Introduction :

Insulation is an essential component of modern building design that helps to reduce energy consumption and maintain comfortable indoor temperatures. Inadequate insulation can lead to energy waste, higher utility bills, and a less comfortable living or working environment. In this report, we will discuss the importance of insulation, the different types of insulation, how insulation is installed, and the benefits of having a well-insulated building.

### The Importance of Insulation :

Insulation is important because it helps to reduce the transfer of heat between the inside and outside of a building. In colder climates, insulation helps to keep warm air inside, while in warmer climates, it helps to keep hot air outside. Insulation can also help to reduce noise transfer, which is important in high-density urban areas.

### Different Types of Insulation :

There are several different types of insulation, each with its own advantages and disadvantages. The most common types of insulation are fiberglass, cellulose, spray foam, membrane, rock wall and rigid foam. Fiberglass insulation is made from spun glass fibers and is commonly used in attics, walls, and floors. Cellulose insulation is made from recycled paper products and is an environmentally friendly option. Spray foam insulation is a more expensive option, but it provides better insulation and helps to reduce air leakage. Rigid foam insulation is a good option for use in walls and roofs because it provides a high level of insulation.

### Installation of Insulation :

Insulation can be installed in new buildings or as an upgrade to existing buildings. The installation process involves determining the type and amount of insulation needed, measuring the space to be insulated, and then cutting and fitting the insulation material into place. In some cases, it may be necessary to remove drywall or other materials to install insulation.

### Benefits of Insulation:

The benefits of insulation are numerous. Insulation can help to reduce energy consumption and lower utility bills by reducing the amount of heating and cooling required to maintain a comfortable indoor temperature. Insulation can also help to improve indoor air quality by reducing the amount of outdoor pollutants that enter the building. In addition, insulation can help to reduce noise transfer and increase the value of a property.

## Method of Insulation :

There are several methods of insulation for buildings, each with its own advantages and disadvantages. The most common methods of insulation include batt insulation, blown-in insulation, spray foam insulation, and rigid foam insulation.

### Batt Insulation :

Batt insulation is a type of insulation that comes in pre-cut pieces, typically made of fiberglass. It is installed between the framing members of walls, floors, and ceilings. This type of insulation is relatively easy to install and is a cost-effective option, making it a popular choice for many builders. However, batt insulation can be difficult to fit around obstructions and may leave gaps or voids if not installed properly.

### Blown-In Insulation :

Blown-in insulation is another common method of insulation that is typically made of cellulose or fiberglass. This type of insulation is blown into open spaces, such as attics and walls, using a special blowing machine. Blown-in insulation is a good option for insulating irregularly shaped spaces, and it can be a cost-effective way to improve energy efficiency. However, blown-in insulation may settle over time and may not be suitable for high-moisture areas.

### Spray Foam Insulation :

Spray foam insulation is a more expensive option, but it provides excellent insulation and helps to reduce air leakage. Spray foam insulation is typically made of polyurethane and is applied in liquid form, which then expands to fill the space. Spray foam insulation is a good option for insulating hard-to-reach areas, and it can help to improve indoor air quality by reducing the amount of outdoor pollutants that enter the building. However, spray foam insulation requires special equipment and training to install, making it a more expensive option.

### Rigid Foam Insulation :

Rigid foam insulation is a type of insulation that is typically made of polystyrene or polyisocyanurate. It is available in various thicknesses and can be used to insulate walls, roofs, and foundations. Rigid foam insulation is a good option for use in walls and roofs because it provides a high level of insulation. However, rigid foam insulation is a more expensive option, and it may not be suitable for all applications.

In addition to these methods, there are also other specialized types of insulation available for specific applications, such as reflective insulation, which is typically used in attics, and radiant barriers, which are used to reflect heat away from the building.

## Capability of materials :

The capability of materials used in insulated buildings depends on their insulating properties, which refers to their ability to reduce the transfer of heat. The insulation capability of a material is determined by its thermal resistance, also known as the R-value. The higher the R-value of a material, the better its insulation capability.

Some common materials used in insulated buildings and their insulation capability include:

### Fiberglass Insulation :

Fiberglass insulation is a popular choice for insulating buildings because of its low cost and relatively high R-value. The R-value of fiberglass insulation ranges from R-2.2 to R-3.8 per inch of thickness.

### Cellulose Insulation :

Cellulose insulation is typically made from recycled paper products and has an R-value of around R-3.2 to R-3.8 per inch of thickness. Cellulose insulation is an environmentally friendly option, but it can be more expensive than other types of insulation.

### Spray Foam Insulation :

Spray foam insulation is a more expensive option, but it provides excellent insulation and helps to reduce air leakage. The R-value of spray foam insulation ranges from R-3.5 to R-7 per inch of thickness.

### Rigid Foam Insulation :

Rigid foam insulation is a good option for use in walls and roofs because it provides a high level of insulation. The R-value of rigid foam insulation ranges from R-4 to R-8 per inch of thickness, depending on the type of foam.

### Reflective Insulation :

Reflective insulation is typically used in attics and has an R-value of around R-3. Reflective insulation works by reflecting heat away from the building, rather than absorbing it.

In addition to the materials used for insulation, the effectiveness of insulation in a building also depends on the quality of installation, as gaps or voids in insulation can reduce its insulating capability. Proper installation is essential for ensuring that the insulation is effective.

## The U-value of a building :

Is a measure of the rate of heat loss through a building element, such as a wall, roof, or window. The lower the U-value, the better the insulation performance of the building element.

The U-value is calculated using the following formula:

$$U = 1 / (R1 + R2 + R3 + \dots + Rn)$$

where U is the overall heat transfer coefficient in watts per square meter Kelvin ( $W/m^2K$ ), R1, R2, R3, and so on are the individual thermal resistances of the different layers of the building element in square meters Kelvin per watt ( $m^2K/W$ ), and n is the total number of layers in the building element.

To calculate the U-value of a wall, for example, you would need to know the thermal resistance of each layer of the wall, including the insulation, the wall cavity, the plasterboard, and the internal and external finishes. These thermal resistances are typically provided in tables and can be obtained from manufacturers, building regulations, or building standards.

Once you have obtained the thermal resistance values for each layer, you can plug them into the formula and calculate the U-value for the wall.

It is important to note that the U-value of a building element can also be affected by factors such as air leakage, thermal bridging, and the type of construction. These factors can increase the overall heat loss and reduce the effectiveness of the insulation.

## Door, window and curtain wall insulation of building :

Obtaining the perfect U-value for a door, window or curtain wall involves selecting the right combination of materials, dimensions, and design features that will provide the best insulation performance. Here are some factors to consider when aiming for the perfect U-value for a window or curtain wall:

1. **Window or Curtain Wall Material:** The material used in the window or curtain wall can affect its insulating properties. Various materials can be used such as aluminum, steel, wood, and composite materials. Each material has its own insulating properties, so it's essential to select a material that provides good insulation.
2. **Glass Type:** The type of glass used in the window or curtain wall can also affect its insulating properties. Double or triple glazed windows provide better insulation than single glazed windows, and low-emissivity (Low-E) coatings can further improve the insulation performance of the glass.
3. **Gas Filling:** Double or triple glazed windows can be filled with gases such as argon or krypton to improve their insulation performance. These gases are denser than air and help to reduce heat transfer through the window.
4. **Spacers:** The spacers between the panes of glass can also affect the insulation performance of the window or curtain wall. Warm edge spacers made from non-metallic materials can provide better insulation than traditional metallic spacers.
5. **Design Features:** The design of the window or curtain wall can also affect its insulation performance. Features such as the size and orientation of the window, the number of panes, and the presence of shading devices can all impact the U-value of the window or curtain wall.
6. **Installation:** Proper installation of the window or curtain wall is essential to ensure that it provides the best insulation performance. Poorly installed windows or curtain walls can allow air infiltration and reduce their insulation effectiveness.

To obtain the perfect U-value for a window or curtain wall, it's essential to work with a professional who can help select the right combination of materials, dimensions, and design features that will provide the best insulation performance. U-value is not the only factor to consider when selecting windows or curtain walls, as other factors such as solar heat gain and air leakage can also impact the energy efficiency of a building. It's important to consider all of these factors when selecting windows or curtain walls for a building.

Obtaining the perfect U-value for doors in a building involves selecting the right combination of materials, dimensions, and design features that will provide the best insulation performance. Here are some factors to consider when aiming for the perfect U-value for doors:

1. **Door Material:** The material used in the door can affect its insulating properties. Various materials can be used such as wood, steel, fiberglass, or aluminum. Each material has its own insulating properties, so it's essential to select a material that provides good insulation.
2. **Insulation:** Doors can be insulated with materials such as foam, honeycomb, or fiberglass to improve their insulation performance. The level of insulation needed will depend on the climate and the building's heating and cooling needs.
3. **Weatherstripping:** Proper weatherstripping is essential to prevent air infiltration and improve the insulation performance of the door. Weatherstripping can be made from materials such as foam, rubber, or felt.
4. **Threshold:** A threshold can be added to the bottom of the door to improve its insulation performance. The threshold can be made from materials such as wood or aluminum and should be installed properly to prevent air infiltration.
5. **Design Features:** The design of the door can also affect its insulation performance. Features such as the size and orientation of the door, the presence of glazing, and the type of hardware can all impact the U-value of the door.
6. **Installation:** Proper installation of the door is essential to ensure that it provides the best insulation performance. Poorly installed doors can allow air infiltration and reduce their insulation effectiveness.

To obtain the perfect U-value for doors in a building, it's essential to work with a professional who can help select the right combination of materials, dimensions, and design features that will provide the best insulation performance. U-value is not the only factor to consider when selecting doors, as other factors such as air leakage and durability can also impact the effectiveness of a door. It's important to consider all of these factors when selecting doors for a building.



## Facade Insulation of building :

Is an effective way to improve its energy efficiency, reduce heating and cooling costs, and increase occupant comfort. Here are the steps involved in insulating the facade of a building:

1. **Assessment:** The first step is to assess the existing facade to determine the type of insulation needed and the best method for installation. The assessment should consider the age of the building, the climate, the orientation of the building, and the building's energy usage.
2. **Choose the insulation material:** Different insulation materials can be used for the facade of a building, such as mineral wool, expanded polystyrene (EPS), extruded polystyrene (XPS), polyurethane foam, or cellulose. Each material has its own insulation properties, cost, and installation requirements, so it's essential to select the right material that meets the building's needs.
3. **Install the insulation material:** The insulation material can be installed on the exterior or interior of the facade. Installing the insulation on the exterior of the building is often the preferred method because it prevents thermal bridging and helps to reduce heat loss. The insulation can be attached to the facade using various methods such as mechanical fasteners, adhesives, or a combination of both.
4. **Cover the insulation:** Once the insulation is installed, it needs to be covered with a protective layer to prevent damage from the elements. This layer can be a finishing material such as stucco, brick, stone, or metal cladding. The finishing material should be carefully selected to ensure it complements the building's aesthetic and provides adequate protection to the insulation material.
5. **Install windows and doors:** The installation of new or replacement windows and doors should be carefully planned to ensure they are properly sealed and don't cause thermal bridging. Energy-efficient windows and doors should be selected to further improve the building's energy performance.
6. **Check for air leaks:** Finally, it's important to check for air leaks around the insulation material and ensure that the insulation is properly sealed. Any air leaks can significantly reduce the effectiveness of the insulation and increase energy costs.

## Sound insulation of building :

Is the process of reducing the transmission of noise between rooms, from outside the building, and between floors. It is an important aspect of building design and construction that can greatly improve the comfort of occupants and their productivity. There are several methods of sound insulation that can be used in buildings, including the following:

### Mass :

Increasing the mass of a building element, such as walls, floors, and ceilings, can reduce the transmission of noise. Materials with high density, such as concrete, masonry, and plaster, are effective at reducing noise transmission.

### Absorption :

Sound absorption is the process of converting sound energy into heat. Materials with high absorption coefficients, such as fiberglass, mineral wool, and acoustic foam, can reduce the transmission of noise by absorbing sound waves.

### Damping :

Sound damping is the process of reducing the vibration of building elements. This is achieved by using materials with high damping coefficients, such as viscoelastic polymers, to reduce the resonance of building elements and prevent them from vibrating and transmitting sound.

### Isolation :

Sound isolation is the process of preventing the transmission of sound waves by creating a barrier between the sound source and the receiver. This can be achieved by using resilient channels, which separate the drywall from the studs, or sound isolation clips, which suspend the drywall from the ceiling.

### Sealing :

Sealing air leaks in the building envelope can reduce the transmission of sound waves. Sealing gaps around windows and doors, electrical outlets, and light fixtures can reduce noise transmission by preventing sound waves from leaking through these gaps.

### Design :

Sound insulation can be improved by designing buildings with acoustics in mind. This can include the placement of rooms, the use of sound-absorbing materials, and the installation of soundproofing elements such as doors and windows.

It's important to consider the specific needs of each building when designing a sound insulation plan. Working with a professional acoustical engineer can help ensure that the most effective methods of sound insulation are used for a particular building. Proper sound insulation can greatly improve the comfort of occupants and their quality of life.

## Table of comparison :

	Insulated Building	Non-Insulated Building
Advantages		
Energy Efficiency	Reduced energy consumption and lower energy bill	Higher energy consumption and bill
Comfort	Improved indoor temperature and noise reduction	Higher indoor temperature and noise levels
Durability	Improved protection against moisture and pests	Greater vulnerability to moisture and pests
Disadvantages		
Initial cost	Higher upfront cost for insulation	Lower upfront cost for insulation
Maintenance	Requires regular maintenance for optimal function	Less maintenance for construction
Flexibility	May limit the use of certain construction methods	More flexible for different construction
Installation time	Longer installation time for insulation	Quicker installation time

## Examples of how to calculate U value :

All information and data is authentic and originates from laboratory experiments.

No.	Layers	Thickness (mm)	Thickness (m)	R value	K Value	
1	Interior paint	1	0.001	0.12	0.008333	
2	Gypsum plaster	20	0.02	0.048	0.416667	
3	Brick wall	200	0.2	0.24	0.82	
4	Cement plaster	20	0.02	0.013	1.538462	
5	Styropore XPS, 27 kg/m <sup>3</sup>	40	0.04	1.25	0.032	
6	Outside paint	1	0.001	0.044	0.022727	
7						U = 0.583

No.	Layers	Thickness (mm)	Thickness (m)	R value	K Value	
1	Interior paint	1	0.001	0.12	0.008333	
2	Gypsum plaster	20	0.02	0.048	0.416667	
3	Brick wall	200	0.2	0.24	0.82	
4	Cement plaster	20	0.02	0.013	1.538462	
5	Styropore EPS , 22 kg/m <sup>3</sup>	40	0.04	1.43	0.028	
6	Outside paint	1	0.001	0.044	0.022727	
7						U = 0.528

No.	Layers	Thickness (mm)	Thickness (m)	R value	K Value	
1	Interior paint	1	0.001	0.12	0.008333	
2	Gypsum plaster	20	0.02	0.048	0.416667	
3	Brick wall	200	0.2	0.24	0.82	
4	Fiber glass	50	0.05	2.2	0.02	
5	Cement plaster	20	0.02	0.013	1.538462	
6	Outside paint	1	0.001	0.044	0.022727	
7						U = 0.375

No.	Layers	Thickness (mm)	Thickness (m)	R value	K Value	
1	Interior paint	1	0.001	0.12	0.008333	
2	Gypsum plaster	20	0.02	0.048	0.416667	
3	Thermston wall	200	0.2	0.363	0.550964	
4	Cement plaster	20	0.02	0.013	1.538462	
5	Styropore XPS , 27kg/m3	40	0.04	1.25	0.032	
6	Outside paint	1	0.001	0.044	0.022727	
7						U = 0.544

## Conclusion :

Insulation is a vital component of modern building design that helps to reduce energy consumption, lower utility bills, and maintain comfortable indoor temperatures. There are several types of insulation available, each with its own advantages and disadvantages. The installation process involves determining the type and amount of insulation needed and then fitting it into place. The benefits of insulation include improved energy efficiency, improved indoor air quality, and increased property value. In conclusion, having a well-insulated building is an important consideration for anyone involved in building design or property management.

